

LIBERATOR™

ATARI®





In the third star system fireballs appear, requiring four shots to destroy. In the ninth star system at the 25th Mission planet a white pulsating "master" base appears on the planet's surface with sensors that can defend against a laser attack by changing the speed and direction of planet rotation. In the eleventh star system, starballs appear that speed up after a hit and take four fireballs before being destroyed. In total there are 60 different planets to challenge the player.

The action never ends for you or the player. With new features and options to make Liberator your most successful mission.

Skill-Step™ Skill-Step allows a player to start a new game at various levels up to level 22. Levels are in increments of three. Bonus points and spaceships are awarded if the player selects and successfully completes a higher level of play. The player selects the skill level by holding "FIRE" when pressing "START."

High Score List—The 10 top plot scores are displayed along with the initials of the players who achieved them. The top 3 scores are permanently stored in memory—even when power is off.

Scoring. Killer Saucer—150
Master Base—100
Enemy Spaceship—50
Satellite—20
Fireball—20
Starball—20
MINI—10

ATARI The First Arcade.



100 Bonus points are awarded for each spaceship remaining at the end of a planet or level. Each level has a Bonus Multiplier applied to all scoring. Planet One has a 1x multiplier, Planet Two has a 2x multiplier, and so on up to Planet Eight which has a 8x multiplier. After Planet Eight the Bonus Multiplier stays at 8x.

OPERATOR OPTIONS

Game Difficulty. Operator selectable for "Easy," "Normal" or "Hard" game play.

Game Lives. Operators may select 4, 5, 6 or 8 ships per game.

Bonus Levels. Selectable for 4 different bonus levels: Bonus every 15,000 points, Bonus every 20,000 points, Bonus every 25,000 points, and Bonus every 30,000 points.

Self-Test. Allows operators to check all game switches and computer functions.

Coin Modes. Includes 17 unique operator-selectable coinage configurations.

Cabinet Dimensions. (Height) = 68 5/8" - 167.8cm (Depth) = 26 1/8" - 66.1cm (Width) = 23 9/16" - 60.5cm.



ATARI INC. 10101 N. DE SOTO AVE. SCOTTSDALE, AZ 85258

72001101 72001101 72001101 72001101 72001101 72001101 72001101 72001101

Distributed by: